


SyncRight GPS Clock

Mounting Instructions




Included Items:

- A. SyncRight Clock Unit
- B. Two (2) Mounting Brackets
- C. GPS Antenna
- D. 10 meters of GPS Antenna Cable


Mounting

SyncRight is weatherproof. It will work both indoors and outdoors.



GPS Antenna Location

Recommended placement of GPS Antenna outside building is as follows:



If the **SyncRight GPS Clock** is to be mounted indoors, the GPS Antenna must still be mounted **OUTDOORS**.

- (1) The GPS Antenna is weatherproof
- (2) The GPS Antenna comes with ten meters of shielded cable
- (3) If ten meters of cable is not enough, please order extra cable from StarComm

- A. Illustration A shows that such position of antenna on building is best and is highly recommended.
- B. Illustration B shows that such position of antenna on building is correct and will receive good signal.
- C. Illustration C shows wrong placement of antenna on building that may affect signal reception.

Important

Power

- a. To turn on the SyncRight GPS Clock, simply plug the power cable to a power source.
- b. The SyncRight GPS Clock Operates at 220 to 240VAC.
- c. An AVR is highly recommended.

Maintenance

- a. The SyncRight GPS Clock requires little to no maintenance however, cleaning of fan screen is recommended to be done at least once a year.

Warranty/Service

- a. Repair Service is covered by warranty for 1 year from product purchase.
- b. Shipping Cost is not covered by warranty.

Customer Care

STAR COMMUNICATIONS HOLDINGS CORP.

37 Samat St., Brgy. Sto. Domingo, Sta. Mesa Heights, Quezon City, M.M.
 Tel:+63 (2) 416 0936 to 0938 Fax:+63 (2) 416 0935
<http://www.starcomm.com.ph> sales@starcomm.com.ph